

# G5e Incremental Reprogramming



JOHN DEERE

## G5e Incremental Reprogramming

### Preparing the USB for G5e Software

1. Create a folder in your computer device's File Manager and name it "G5e".
2. Download the latest software from StellarSupport™ onto your computer device and save it in your newly created "G5e" folder.
3. Plug in your USB to your computer device and copy the new software from the "G5e" folder onto the USB drive.
4. Select the file that is now on your desktop and copy the new software onto the USB drive.

### At Machine with G5e display

1. Identify the G5e USB port on the bottom of the display and remove cover.
2. Insert your USB with the new software.
3. At the display, follow the steps below to initiate incremental reprogramming of the G5e:
  - a. Select "Menu", "System" and then "Software Manager".
  - b. From "Installations & Updates" select "Check for updates on USB drive"
  - c. Select "View Updates for the Display" if you are installing a newer software version and Select "Next".
  - d. Select "View Previous Software Versions for the Display" if you are installing an older version and Select "Next".
  - e. Select which version you would like to install and Select "OK".
    - a. If multiple version packages are available in USB, select the version button and select the version from available list.
  - f. Select "Install" and Accept the Caution Screen.
  - g. The Installation Process will take about 7 minutes to complete extraction and installation process.